

Wrapping Up

In this tutorial, you learned how to configure and connect blocks in ChipInventor to **create an SPI system for an accelerometer**, check for errors in simulation, synthesize the circuit, and program the FPGA.

If you have any questions, review the steps, make adjustments, and keep exploring more advanced projects in ChipInventor!

Revision #1

Created 3 April 2025 19:20:04 by Caroline

Updated 3 April 2025 19:20:48 by Caroline