

Hardware Validation

After programming the FPGA, let's test the hardware:

- On the top menu, click **Main**.
- Access the **Serial Console**.
- Configure the **correct baud rate** (e.g., 115200 baud).
- On the serial monitor, view the data received from the accelerometer.
- If data is not received correctly, review the blocks and parameters in ChipInventor.

Revision #1

Created 3 April 2025 19:19:28 by Caroline

Updated 3 April 2025 19:19:58 by Caroline